

Using These Measurements

This document contains the approximate room measurements for Smith Hall. We recommend that it be viewed in Adobe Acrobat, which can be downloaded at Adobe's website, www.adobe.com/reader.

Because there are many configurations available for every area, these layouts and measurements should be seen as general guidelines. All measurements and drawings are made to scale, however the drawings may not reflect all aspects of every room. There may be architectural features that do not allow furniture to fit into a space. We recommend saving all receipts for purchased furnishings just in case they won't fit.

The Housing and Residence Life main office is available for questions at reslife@samford.edu or (205)726-2956. We will do our best to provide any details or measurements we currently possess but we cannot promise to provide answers to all possible questions. Visiting rooms before move-in is not allowed.

Finding Your Room Configuration


In order to find the configuration for your room, we recommend you utilize the Find command built into most PDF viewers. In Adobe Acrobat, use your mouse to click on Find under the Edit menu. You can also press Control+F if you use Windows or Command+F if you use a Mac.

If you were searching for Smith 302, type in "302" and hit Enter. It should take you to the page that contains the measurements for your room. You can verify this by looking at the bottom left of the page under the "Configuration Notes"; it will list all rooms which that configuration is applicable to.


Other Tips

All Samford owned furniture must stay in the room. Residents are welcome to bring in their own furniture and rearrange provided furniture but the Samford owned furniture may not leave the room or be stored elsewhere. Furniture may not be in the same layout as the drawing at move-in.







Applicable to Smith 251 and 352 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact











Applicable to Smith 103, 104, 107, 108, 151, 155, 156, 159, 205, 206, 208, 211, 253, 256, 258, 259, 305, 306, 308, 311, 353, 354, 357, 359, 360 All drawings are 1/4"=1'-0" scale

Dimensions are meant to be general figures and may not be exact








Applicable to Smith 101, 105, 106. 109, 153, 154, 157, 158, 203, 204, 207, 209, 210, 255, 257, 260, 303, 304, 307, 309, 310, 355, 356, 358, 361 All drawings are 1/4"=1'-0" scale


Dimensions are meant to be general figures and may not be exact






Applicable to Smith 111, 160, 212, 262, 312, 363 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact






Applicable to Smith 110, 161, 213, 261, 313, 362 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact







Applicable to Smith 113, 162, 214, 264, 314, 365 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact









Applicable to Smith 112, 163, 215, 263, 315, 364 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact











Applicable to Smith 200 and 300 BC All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact









Applicable to Smith 452 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact









Applicable to Smith 402 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact









Applicable to Smith 404 and 453 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact









Applicable to Smith 403 and 454 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact









Applicable to Smith 405 and 456 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact









Applicable to Smith 406 and 455 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact









Applicable to Smith 407 and 458 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact









Applicable to Smith 408 and 457 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact









Applicable to Smith 409 and 460 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact








Applicable to Smith 410 and 459 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact





Applicable to Smith 202 and 302 All drawings are 1/4"=1'-0" scale Dimensions are meant to be general figures and may not be exact

